



# ILLUSTRATION BOOKLET

## PARTS PICTORIAL




B1




C2




C3




C5




C6




C4



PICTORIAL 1




PICTORIAL 2




PICTORIAL 3


S1 S2  
10-HOLE SOCKET 5-HOLE SOCKET



PICTORIAL 2




PICTORIAL 3



PICTORIAL 4

MARK "2550" OR "2975" HERE



HIGH  
VOLTAGE  
AREA

CIRCUIT BOARD  
SUPPORT

MAIN  
CIRCUIT BOARD


PRESELECTOR  
CIRCUIT BOARD

SHORTER  
PINS


15-PIN  
PLUG

PRESELECTOR


PICTORIAL 5



PICTORIAL 6



PICTORIAL 7



**SCHEMATIC OF THE  
HEATHKIT®  
170 HZ PRESELECTOR  
CIRCUIT BOARD ACCESSORY  
MODEL HDA-3030-4**

**NOTES:**

1. RESISTORS ARE IN OHMS (K = 1000).
2. CAPACITORS ARE IN  $\mu\text{F}$  (MICOFARADS).
3.  $\nabla$  THIS SYMBOL INDICATES CIRCUIT BOARD GROUND.
4.  $\wedge$  THIS SYMBOL INDICATES A CIRCUIT BOARD CONNECTOR PIN.